


LoversportableKTV
UserManual



REV : 20140322P01

CATALOGUE

1、The system connection diagram. 1

2、Product introductions. 2

3、Charging introductions. 5

4、Parameter. 7

5、Attention. 7

6、Simple fault handing. 7

7、Warranty declaration. 8

8、Environment declaration. 9


9、Warranty card. 9

PREFACE

Dear Customers:

Thank you for choosing the new generation lover portable KTV product from our company. This product is to use the Hi-tech Technology and new original design, and it infuses the human spirit of pursuing joy and enjoying the entertainment into the product. Owning the lovers portable KTV, you just need to connect the audio player, then you can practice singing easily at any time. It will help you to fulfill your music dream.


1、The system connection diagram



2、Product introductions

1. Please store the correct audio and video format files, such as MP3、3GP、MP4、MKV and so on:
- (1) Please plug one side of ①, ③ or ④ wire into the output port of the audio devices, the other side is to plug into the output port of the KTV devices;
- (2) Please plug the ② wire into the output port of the lovers portable KTV Devices;
- (3) Please turn on the KTV power, then the light will become green, press the MIC and the answer key, after that, you can sing the song.

1. Mobile phone chain graph




- Download and install the software: search the “chang ba” , “tian sound K song” or “K song da ren” applications from the internet, then download to the mobile phone.


- A. K song: connect the mobile phone and lovers portable KTV, open the “K song” software, click the song you are going to sing.
- portable KTV with the ③ white wire of iphone, open the “K song”
- B. Recording with Android mobile phone: connect the mobile phone and software, then you can enjoy K song) The standard recording wire matches the 3.5mm jack of Android smartphone.
- C. Recording with Iphone: connect the mobile phone and portable KTV with the ④ white wire of iphone, open the “K song” software, then turn on the power of KTV, after that you can enjoy K song.

After connecting the device, open the “K song” software then turn on the MIC power. If there is the aftersound, please restart the MIC power.

II. Computer link figure



Recorded in the link schematic diagram




- Software download: Searching the “ku wo K song” from the internet, then download and install the application in the computer.
- A. K song: Connect the computer and portable KTV, open the “ku wo K song” software, click the songs you are going to sing, then you can enjoy yourself. If you want to hide the shakelight, please click accompaniment; If the volume is too big or small, please adjust the software of “ku wo K song” to meet your Requirement.
- B. Recording with computer: Connect computer and KTV with ① and ② wires, turn on the mute button of the MIC of the computer, then open the “ku wo K song” software and click the songs and press the recording button. After finishing singing your song, then press “stop” button and preserve. If you want to hide the shakelight, please click accompaniment; If the volume is too big or small, please adjust the software of “ku wo K song” to meet your requirement.


3、Charging introductions

- Charging the MIC in shutdown situation, the indicated light will show red. Charging the MIC with turning on the power, the indicated light will show red and green colors.
1. Also you can choose the DC5V adapter to charge the KTV;
2. Turn on the computer and charging the KTV device;
3. For the first charge, please charge 8 hours. From the next time, charging 4-5 hours is enough;

Mobile DVD connection diagram:



Charging schematic:




Parent-child duet



There is only a mother good.....

Mama of children like a treasure

Couples duet



tomorrow to the whitehead

Today I want to marry you

4、Parameter

Tone arm: capacitive

Output power: 10mW

Frequency: 28Hz-20Kh

Reverberation model: Sound reverberation of the echo

Power supply model: Built-in battery

Maximum sound pressure level: > 126Db 1Kh THD < 1%

Charging source: DC5V

5、Attention

- *If the device appears the smoking or other abnormal issues, please contact the local dealer or you can dial the phone number of the after sales service department in our company;
- *If the inside of the device suffers the rain or damp, please remove the device to the vent, Remark: Do not allow to toast this device in high temperature, otherwise it will be easily destroyed or the components will lose their efficacy;
- *Please keep the MIC far away from the fire;
- *Please do not drop the device to avoid falling damage;

6、Simple fault handing

Problem situation	Issues	Reasons	Solution
1	Indicator Light can not work	Do not turn on the power or our of battery	⊙ Please check if the green light work ⊙ Charge the MIC
2	No voice come out from MIC	MIC volume setting not correctly	Adjust the volume of the MIC
3	No reverberation effect	Reverberation setting issue	Adjust the volume of the reverberation
4	Small volume	The position of the MIC not correctly	Adjust and fix the height of the MIC

7、Warranty declaration

Dear Users, Thanks for your supports and orders. Please read the following matters to protect your rights, clear the responsibilities and obligations, which include Repair, Replacement, Return (Abbreviation: 3R) from the distribution and factory

1. (Product Warranty Card) is the necessary certificate for supply the free after sale service in the warranty period from us.
2. According to the rule, the one sell products, the one is responsible for the 3R
3. We promise, If the quality problems appear within seven days from the date of sale, you can apply for replacement and repair;
- If the quality problems appear within 1 year, you can apply for free repair.
- Please carefully written the (Product Warranty Card) after you purchase from the sellers.
4. There isn't 3R service for the following situations:
- (1) Over the warranty time of 3R
- (2) Not according to the instructions to use, maintenance, custody of the damage caused.
- (3) Not assume 3 packets of open specially damage repair
- (4) Without (warranty card)
- (5) The content of the (warranty card) is not coincident with the physical product or altered.
- (6) Damage is caused by force majeure
5. Our company reserves the right to explain the terms of the event

8、Environment declaration

Standard of the ROHS

Part name	Standard of the ROHS					
	p b	Hg	c d	Cr(VI)	PBB	PADE
Plastic cover	×	○	○	○	×	○
Painting	×	○	○	○	○	×
PCBA	×	○	○	○	○	○
Hardware accessories	×	○	○	×	○	○
Electronics components	×	○	○	○	○	×
Package	×	○	○	○	○	○

- Said the toxic substances in the parts all in homogeneous material content in the SJ/T11363-2006 standard of set limit to request;
- × Said the toxic and harmful substances in the parts of at least one homogeneous material content beyond the SJ/T11363-2006 standard requirements of set limit to:
- RECORD: 80% parts of the product are made of the Non-toxic material.
- Because the technology is limited in the world, the material or the components contain the toxic can not avoid or replace at present.

9、Warranty card

Product model: _____

Purchase date: _____


Agent: _____

Invoice date: _____

Tel: _____

Customer's name: _____

Zip code: _____



The company will continue to product innovation, and are subject to change without prior notice.